



STACKING CLIP INSTALLATION INSTRUCTIONS

Check carefully to ensure that all parts listed are included. If any are missing, please call 1-800-413-8665 and ask for the Sales Department.

INSTALLATION INSTRUCTIONS:

Four (4) stacking clips with adhesive foam are provided for customer convenience of stacking product, preventing movement between units.

- 1. Locate unit being stacked on top of base unit, users preference.*
- 2. Remove adhesive tape from stacking clip and align under each corner of top unit adhering to base unit top.*

NOTE: *Alignment of corners to base unit is critical before applying adhesive stacking clip.*